

## **SAFIRE SF-AC1003KMF-WR**



Access reader - Access by MF card and PIN - LED and acoustic indicator - Wiegand 26/34 | RS485 - Compatible with Safire - Valid for interior

- Safire
- Access reader for controller
- Access by MF card and touch keypad
- LED indicator
- Wiegand 26/34 and RS485
- Compatible with Safire controllers