

SAFIRE SF-AC1101DS-WR



Access reader - Access by MF DESFire card - LED and acoustic indicator - Wiegand 26/34 | RS485 - Compatible with Safire - Suitable for exterior IP65

- Safire
- Access reader for controller
- Access by MF DESFire card
- LED indicator
- Wiegand 26/34 and RS485
- Suitable for exterior IP65
- Compatible with Safire controllers